

Fitting Paper guide to CLP 9000R (part number 2000399)

Removing the peeler unit and the lower “present sensor” assembly

1 – Removing screws

a - Two either side of the platen roller

b - One below Platen fixing clamp

c - One under lower present sensor

2 – Remove two fixing screws holding lower present sensor assembly

3 – Roll printer on to its back panel

Undo fixing screw holding the lower part of the peeler mechanism

4 – Ease the assembly out of position in the printer.

5 – Fit the paper guide, using the 4 screws from the peeler assembly. It may be necessary to fit some washers at any one or all of the fixing points when tightening the screws. This is due to these parts being hand made and any one of the fixing points may pull the side frame out of place slightly, if there is any in-accuracy in the bending of the steel during manufacture. The included picture shows where the washers are most likely to be needed. Each guide is included with 4 spare washers and a slightly longer screw if needed.



Setting up the printer

Turn on printer

Press Mode button

Press button marked Up until "After Print"

Press Select

Press button marked Up until "Rewinder"

Press Select then Up button until "ON"

Press Select, then Exit until "After Print"

Press Up Button until "Save Settings"

Press Select, then Up button to move curser under "Yes"

Press Select, then Exit until control panel shows "Ready"

Press the Button Marked Feed and the paper should feed out and the "Rewinder should operate.

Load Paper into Rewinder assembly and start printing.